







Cable-Ready® Tensioner and Bit

Assembly/Disassembly
Instructions



Assembly Instructions



Disassembly Instructions

1. Disassemble the tensioning bit from the tensioner
2. Remove lever arm from nozzle



+H124972232014001/\$100726G10-

97-2232-014-00 1006-T11 Printed in USA ©2010 Zimmer, Inc.